



**INSTALLATION INSTRUCTIONS**

1. Remove the cap from the end of the rod.

2. Insert the rod into the hole in the wall.

3. Tighten the nut and washer to secure the rod.

4. Repeat steps 1-3 for the remaining rods.

5. The rods are now ready for use.

© 2000 [Company Name]

