

Insert the small metal rods into the designated holes and use the zip ties to secure the top and bottom sections of the snowman.

Insert the hand and hat tubes into the holes as shown above. Connect the end of the LED wire to the adapter and turn clockwise firmly. Plug the adapter to an appropriate power source.