



### WOODEN NATIVITY STABLE ASSEMBLY INSTRUCTIONS

PLACE BASE ON LEVEL GROUND & LOWER BACK WALL INTO BASE BY ALIGNING 3 SCREWS WITH WALL PANEL(1.) AND TIGHTEN SCREWS WITH WING NUTS SUPPLIED. ATTACH TOP OF BACK WALL BY ALIGNING 2 SCREWS WITH HOLES(2.) AND TIGHTEN WING NUTS. ATTACH LEFT WALL BY ALIGNING 3 SCREWS INTO BACK WALL AND ONE SCREW INTO BASE(3.), TIGHTEN ALL WING NUTS. ATTACH MIDDLE WALL BY ALIGNING ONE SCREW INTO BACK WALL AND ONE SCREW INTO BASE (4.), TIGHTEN ALL WING NUTS. ATTACH LEFT ROOF AND FRONT ROOF PANEL BY SLIDING FRONT PANEL INTO TRACK ON FRONT OF ROOF. THEN ATTACH ROOF TO TOP OF BACK WALL BY ALIGNING SCREWS WITH HOLES AND ATTACHING WING NUTS SECURELY(5.), ATTACH RIGHT ROOF AND FRONT ROOF PANEL BY SLIDING FRONT PANEL INTO TRACK ON FRONT OF ROOF. THEN ATTACH ROOF TO TOP OF BACK WALL AND ALIGN WOODEN PEG IN FRONT OF RIGHT ROOF WITH HOLE ON LEFT ROOF, YOUR WOODEN NATIVITY IS NOW ASSEMBLED(6.)