

ASSEMBLY INSTRUCTIONS

CHECK THE INVENTORY

You will need a UL approved power strip that is rated for at least 5 AMPS or more (not included).

1. Pre-lit tree top (Section A)
2. Pre-lit tree middle (Section B)
3. Pre-lit tree bottom (Section C)
4. Replacement bulbs (incandescent only) and fuses
5. Collapsible stand with 3 triangular screws attached in a plastic bag.
Stand has threaded feet for balance adjustment.

CAUTION

For incandescent pre-lit trees, do not overload. Connect a maximum of three series or series parallel connected lighting strings or decorative outfits to each load fitting. Do not interconnect different types of products.

Before assembling the tree, test each section to ensure lights are working properly. Take the plug stack from each section and plug it into an extension cord or power strip. If there is a light set that does not light, refer to the TROUBLE SHOOTING section. If all light strands are working properly continue setup. Repeat for each section.

Your item has been carefully packaged for transit, however due to the nature of the materials used, some debris may appear in the bottom of the packaging, while unpacking or while setting up.


ASSEMBLY

1. POSITION AND SET UP TREE STAND

- Place tree stand in desired location.
- Unfold tree stand until the legs are perpendicular and the screw holes are aligned.
- Insert the tree screws into the screw holes and turn 3-4 turns only (if the screws are inserted too far you will not be able to fully insert the tree pole).
- The feet on the stand are threaded for balance adjustment. Simply screw in or unscrew the feet on the stand to change the overall balance on the tree.
- Plug the tree stand into an extension cord or wall outlet.


2. INSERT THE BOTTOM SECTION INTO THE TREE STAND

- Insert the bottom tree section (Section "C") into the stand.
- Let the hinged branches fall into place.
- Adjust the branch tips for desired appearance.
- Tighten screws in stand to secure the tree.




3. INSERT THE MIDDLE SECTION INTO THE BOTTOM TREE SECTION

- Remove the plastic cap at the end of the metal pole.
- Insert the middle section (Section "B") into the bottom section.
- Find the plug from the middle section that plugs into the bottom tree section and connect the plugs.
- Adjust the branch tips for desired appearance (some people chose to perform this step when the tree is fully assembled).



4. SHAPE THE TREE TOP AND INSERT INTO THE MIDDLE SECTION

- Adjust the tips and shape the tree top before inserting the topper.
- Insert tree top (Section "A") into middle section.
- Find the plug from the tree top that plugs into the middle tree section and connect the plugs.
- Plug the tree into the electrical outlet in the wall.
- The tree top can be rotated as part of the tree shaping process. For best results rotate the tree top so the bottom layer of branches on the tree top is offset from the top layer of branches on the middle layer.



5. MAKE FINAL ADJUSTMENTS TO TREE TIPS AND DECORATE IF DESIRED.

INCANDESCENT LIGHT CARE

If bulbs burn out, be sure to replace them with replacement bulbs (included). This will extend the life of the remaining bulbs. When not in use, store in a cool dry location.

Safety First:

Unplug the power supply cord when replacing lamps and fuses. Never change a fuse while the power supply cord is plugged into an outlet. Replace lamps with incandescent mini lights only.

Troubleshooting:

If a strand of lights is out this means that there is a missing bulb or a loose connection in the strand on one of the bulbs. Follow these steps to check your strand.

1. Check to be sure that all the cords are plugged into each other.
2. If the item still fails to light, check the fuses in each light strand - use only 125 volt fuse, 5 amp maximum (included).

TREE STORAGE

1. Unplug power cord.
2. Remove decorations.
3. Lift each section directly up.
4. Separate the tree sections (starting at the top). Fold branches up to avoid crushing the tips. You can tie the branches up to make the section easier to handle and set up for future use.
5. Unscrew the tree stand to release the bottom section. Fold stand and tighten screws back into stand to prevent losing the screws.
6. Store in a cool, dry area.