

# INSTRUCTIONS


This unit is made for display purposes and should not be regarded as a toy. Read the following carefully to ensure satisfactory and safe operation of this unit. Please keep this instruction for future reference.

## Feature:

1. The item is operated with 3 "AA" size batteries (Not included) with dome effect.
2. Battery powered color changing LED lights for the light source of the product.
3. Battery powered motor and creates rotor stirring effect with glitter flowing in the liquid inside the Santa/snowman
4. Cord-free decoration piece, can easily be displayed anywhere indoor.
5. Power-saving LED can ensure longer battery life.
6. LED 'S are not replaceable.


## Operating Procedure:

1. Carefully remove all packing material such as PVC wrappings, tags, fasteners, etc.
2. Seek the bottom for the battery compartment. Insert 3 x "AA" batteries with correct polarity. Alkaline batteries are strongly recommended for best performance.
3. Tighten the battery compartment screw.
4. Move the switch to "ON" position to light up the unit in fantastic glowing.
5. For power off, move the switch to "OFF".



## Attention:

1. Adult supervision is required when changing batteries.
2. Make sure to turn switch "OFF" when changing of batteries.
3. Batteries are to be inserted with the correct polarity.
4. Do not attempt to recharge non-rechargeable batteries.
5. Rechargeable batteries are to be removed from the item before being recharged.
6. Rechargeable batteries are only to be charged under adult supervision.
7. In usage, do not mix old and new batteries or batteries of different types, such as alkaline, standard(carbon zinc) or rechargeable (nickel cadmium or nickel metal hydride) batteries.
8. The supply terminals are not to be short-circuited under any circumstances.
9. Remove exhausted batteries from item.
10. Replace batteries when the light is faint or movement is distorted. Replace all batteries at the same time.
11. Only use recommended batteries or those of the same or equivalent type.
12. Do not allow any parts of the unit to come into contact with heat or flame.
13. Never throw batteries in a fire or attempt to open outer casing. Batteries may explode or leak.
14. Remove all batteries if the item is left unattended for a long period of time.
15. Batteries should be recycled or disposed of as per manufacturer's recommendations.
16. Batteries are harmful if swallowed, so keep away from young children.
17. Avoid a direct view into the LED.



**For indoor use only**  
**Made in China**

12-24038A/12-24038B/12-24038C  
09-104078/09-104080  
14-24067A/14-24067B