











Assembly Instructions


Parts List:

No.	Picture	Qty	No.	Picture	Qty	No.	Picture	Qty
A		1	B		1	C		1
D		1	E		1	F		1
G		1	H		2	I		4


Step 1




Step 2




Step 3



Step 4



Step 5



Step 6



Nutcracker requires 3xAA Batteries (not included), and Lantern requires 1xAA Batteries (not included). Either Alkaline or Rechargeable Ni-MH for longer life.