

# ASSEMBLY INSTRUCTIONS

NOTE: This tree may utilize light sets that are marked for indoor and outdoor use. However, this tree is only suitable for indoor use.

1. Before you start to assemble your tree, choose a location near a wall outlet. Assemble the tree stand and place on a level surface.
2. Pull apart the legs of the stand so that they are "X" shape. Lock the stand in position with the 3 eye bolts on the outside metal tab.
3. Screw 3 eye bolts through the hole on the inside metal tab.
4. Carefully insert the bottom section of the tree into assembled stand. Make sure the pole is firmly inserted into stand and turn screws so they touch tree trunk. Stand tree up and straighten by adjusting screws in or out then tighten screws.
5. Insert the middle section into the bottom section, and insert the tree top into the middle section .
6. Allow branches to fall into place or gently pull up and out. When adjusting branches be sure that all wires are free of branch hinges.
7. The light string on the tree top will be plugged into the end connector of the lights string at the top of the tree middle section. The light string in the tree middle section needs to plug into the extension cord which installed on the bottom of the tree middle section. The light strings on the tree bottom section needs to up plug into the extension cord. then the plug on the extension cord needs to insert into the wall outlet. Your entire tree should now be lit. For the details lights connection, please see the drawing on the 2<sup>nd</sup> page. If some bulbs do not light, search for any loose plugs, broken, loose or missing bulbs. (See trouble shooting section ) Keep tree plugged in while shaping your tree. Should a light flicker while doing this, check for the bulb(s) that may have caused the trouble.
8. Begin to shape the branches from the bottom to the top. Start with tips farthest from the pole, one to the right, one to the left and one at the center of the main stem.
9. After shaping the whole tree, step back and take an overall look. Shift branches to fill any gaps. Slightly up sweep all branch tips for a uniform look. Your tree is now ready to decorate and enjoy.

## STORAGE:

1. Unplug cord from the wall outlet and remove all ornaments and decorations.
2. Unplug each section, keep each stack of lights connected together.
3. Gently lift off the top and middle sections, and remove the bottom section from the tree stand. Carefully place the tree in its box and tape it shut. DO NOT STORE TREE IN A DAMP AREA OR IN AN AREA WHERE THE TEMPERATURE EXCEEDS 100°F.

Top  
View



Side  
View




*FLAME RETARDANT*


## TROUBLE SHOOTING INSTRUCTIONS

### If Lights Do Not Work:

1. Check whether the cord is properly plugged into the outlet.
2. Be sure there is power to the outlet.
3. Check whether all plugs within the tree are securely connected.
4. Check whether all bulbs are tightly fixed inside the lamp holders.
5. If a bulb is blown, replace the faulty bulb following the below diagram. There are spare bulbs included for easy replacement.



7. If none of the lights are working, check the fuse in extension cord. If fuse is blown, replace the blown fuse following the below diagram. There is a spare fuse included for easy replacement.



**WARNING – Risk of Fire and Electric Shock:**

1. Read all instructions and warning tags included with this tree.
2. For Indoor Use Only.
3. Do not place near gas or electric heaters, radiator, fireplaces, candles, or other similar sources of heat.
4. Place on a level, hard, flat surface; do not place where tree is likely to wobble due to uneven floors or thick carpeting.
5. Do not use candles on tree.
6. After assembling the tree and adding decorations, make sure the tree is stable. If tree is not stable, shift the weight of decorations, and use support wires to walls and/or window frames (make sure they are secure also).
7. Do not overload extension cords or power strips, see ratings on those devices and check the rating label of the tree for compatibility.
8. Do not install near fountains, bathtubs, sinks, or other wet areas.

